



TRANSPORT
STYLING

2624-931/931B
2624-931L/931LB

MONTERINGSANVISNING



Fabrikat
Ford

Modell
Transit Custom 2013-



Montagetid
30 minuter

