

FITTING INSTRUCTIONS FIT529

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

ISUZU D-MAX 2012+

P/N BG537

1. Clean and open bonnet
2. Test Bonnet Guard on the bonnet and note 2 weather-strip fasteners in bonnet that correspond with 2 pre-drilled holes in Bonnet Guard.
3. Remove these 2 plastic fasteners.
4. Remove the bonnet edge trim by undoing the nuts attaching the trim to the bonnet.
5. Offer the Bonnet Guard into position, lining up the outer 2 holes with the corresponding in the bonnet. (the Bonnet Guard goes between the bonnet and rubber weather-strip).
6. Firmly affix into position using the supplied push pins bases and STP screws.
7. Note the 2 x central holes in the Bonnet Guard and where they line up on to the bonnet Apply the supplied anti abrasive tape to this position.
8. Fit supplied steel clips to the bonnet edge, over the anti-abrasive tape , so the holes line up with the holes in the Bonnet Guard .
9. Fasten in place with the supplied machine screws and cap assembly
10. Replace chrome edge trim and fasten securely with the original nuts.
11. To remove , reverse the above procedure.

